VGN-FS70B/FS30B/FS20/FS90PS/FS90S VGN-FS570/FS550/FS550P/FS540P/FS530B/FS520B/FS500/FS500P/FS500B/FS550F VGN-FS195XP/FS115Z/FS115S/FS115M/FS115E/FS195VP/FS115B/ FS115ZR/FS115MR VGN-FS15C/FS18CP/FS18GP/FS18SP/FS18LP/FS18TP/ FS15GP/ FS15SP/ FS15LP/ FS15TP

SERVICE MANUAL

	VGN-FS70B
	VGN-FS50B
1	VGN-FS30B
,	VGN-FS20
	VGN-FS90PS *
	VGN-FS90S *
	VGN-FS570
	VGN-FS550
	VGN-FS550P
	VGN-FS540P
ΔМ	VGN-FS530B
ΑМ	VGN-FS520B
	VGN-FS500 *
	VGN-FS500P *
	VGN-FS500B *
	VGN-FS550F
	VGN-FS195XP
	VGN-FS115Z
EU	VGN-FS115S
	VGN-FS115M
	VGN-FS115E

<i>-</i> \ .	IOAL
	VGN-FS195VP
EU	VGN-FS115B
EU	VGN-FS115ZR
	VGN-FS115MR
	VGN-FS18CP
	VGN-FS15C
	VGN-FS18GP
	VGN-FS18SP
AO	VGN-FS18LP
AU	VGN-FS18TP
	VGN-FS15GP
	VGN-FS15SP
	VGN-FS15LP
	VGN-FS15TP

*: CTO Model

Revision History

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation











PERSONAL COMPUTER

SONY

Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trade m a r k s or registered of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries. The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, AMD logo, AMD Duron and combinations there of, 3Dnow!, are trademarks of Advanced micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks if Intel Corporation. Transmeta, the Transmeta logo, Crusoe processor, the Crusoe logo and combination there of are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, Hotsync, PalmModem, and palm OS are registered trademarks, and the Hotsync logo and Palm are trademarks of Plam, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrora, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc. All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners. In this manual, the (TM)or(R)mark are not specified.

Caution Markings foe Lithium/Ion Battery-

The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

Discard used batteries according to the Manufacturer'

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C(212°F) or incinerate. Dispose of used battery promptly. Keep Away from children..

CAUTION: Changing the back up battery.

Overcharging, short circuiting, reverse charging, multilati on or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.

· If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection..

Service and Inspection Precautions

*1.Obey precautionary markings and instructions

* Labels and stamps on the cabinet,
*chassis, and components are as
*requiring special precautions. Be

*sure to observe these precautions,

*as well as all precautions listed in

*the operating manual and other

*associated documents..

*2.Use designated parts only

*The set's components possess important safety
*characteristics, such as noncombustibility and the
*ability to tolerate large voltages.

* Be sure that replacement parts possess the same
*safety characteristics as the originals. Also
*remember that the mark, *which appears in circuit
*diagrams and parts lists, denotes components that
*have particularly important safety functions be extra
*sure to use only the designated components.

*3. Always follow the original design when *mounting parts and routing wires

*The original layout includes various

*safety features, such as inclusion of

*insulating materials (tubes and tape) and

*the mounting of parts above the printer

*board. In addition, internal wiring has

*been routed and clamped so as to keep it

away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicat the original layout.

4. Inspect after completing service

After servicing, inspect to make Sure that all screws, components, And wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components.

Never reuse components. Also remember that the negative side of tantalum capacitors is easily Damaged by heat.

6. When handing flexible print boards.

- \cdot The temperature of the soldering-Iron tip shoul be about 270 $^{\circ}$ C.
- Do not apply the tip more than three times to the same pattern.
- · Handle patterns with care; never apply force

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

TABLE OF CONTENTS

Section	Title	Page
Chapter 1.	SPECIFICATIONS	
1-1.Specifi	cations	1-1
1-2.CTO Ir	nformation	1-2
1-3. BTO I	nformation	1-5
Chapter 2.	BLOCK DIAGRAM	
2-1. VGN-F	S Series	2-1
Chapter3.	FRAME HARNESS	
3-1. VGN-F	S Series	3-1
Chapter 4.	EXPLODED VIEW AND P	ARTS LIST
Screws		
S-1.S	crews	4-2
Palmrest		
P-1.Pa	almrest	4-3
Main Board	d	
M-1.M	lain Board	4-5
Bottom		
B-1.B	ottom	4-7
CABINNET	KBCOVER	
C-1.C	ABINNET KBCOVER	4-9
LCD		
L-1.LC	CD	4-10
ODD		
D-1.0	DD	4-13
HDD		
H-1.H	DD	4-14
ACCESSOR	RIES	
A-1.A	CCESSORIES	4-15

Section	Title		Pag
SUBSTITU	JTION PAR	TS LIST	
T-1	SUBSTITU	JTION PARTS LIST	Γ4-18
DIP Swite	ch		4-19
Chapter!	5.OTHER		
5-	·1.Replacin	g the CPU	5-1
5-	-2.Wiring tl	he W-LAN CABLE.	5-2

History of the changes is shown as the "Revision History" at the end of this data.

CHAPTER1. SPECIFICATIONS

1-1. Specifications

			J			
	VGN-FS70B	VGN-FS50B	VGN-FS30B	VGN-FS20	VGN-FS90PS*/FS90S	
CPU	Pentium-M 740(Do1.73)	Pentium-M 730(Do1.6)	Celeron-M 360(Do1.6)	Celeron-M 360(Do1.6)	*1)	
Graphic	NV44M	915GM	915GM	915GM	*2)	
	15.4"WSXGA+	15.4"WXGA	15.4"WXGA	15.4"WXGA	*2\	
LCD	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	*3)	
HDD	80GB	80GB	80GB	80GB	*4)	
MEMORY(Slot1)	256MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333		
MEMORY(Slot2)	256MB DDR333	256MB DDR333	-	-	*5)	
QUANTITY[STANDARD/MAX]	512MB/2GB	512MB/2GB	256MB/2GB	256MB/2GB		
OPT-DRIVE	Super Multi Drive DL	Super Multi Drive DL	Super Multi Drive DL	Super Multi Drive DL	Super Multi Drive DL Combo	
AC adaptor	AC19V11	AC19V11	AC19V11	AC19V11	AC19V10	
Battery	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	
Wireless LAN	0	0	0	0	0	
W-Mouse	X	Х	Х	Х	O/X	
Memory Card Adapter	0	0	0	0	O/X	
USB FLOPPY DISK DRIVE	X	0	0	0	Х	
os	XP Home	XP Home	XP Home	XP Home	XP Home/XP Pro	

^{*1)}Celeron-M 360,Pentium-M 730,Pentium-M 740,Pentium-M 770 *2)NV44M,915GM *3)15.4"WSAGA+(CB),15.4"WXGA(HC) *4)100GB,80GB,60GB,40GB *5)512MB*2,512MB*1,256MB*1

^{*9)512}MB*1,512MB*2,256MB*1,256MB*2 *10)Combo,DVD+/-RW DL,DVD-ROM *11)None, 802.11b/g, 802.11a/b/g

	.,.	,	, , ,					
				Α	М			
	VGN-FS570	VGN-FS550	VGN-FS550P	FS540P	VGN-FS530B	VGN-FS520B	VGN-FS500*/FS500P*/FS500B*	VGN-FS550F
CPU	Pentium-M 740(Do1.73)	Pentium-M 730(Do1.6) *6)		Pentium-M 730(Do1.6)				
Graphic	915GM	915GM	915GM	915GM 915GM 915GM		915GM	*7)	915GM
	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA
LCD	(Clear Black)	(Clear Black)	(Clear Black)	(High Brightness)	(High Brightness)	(High Brightness)	(Clear Black)	(High Brightness)
HDD	100GB	80GB	80GB	80GB	60GB	40GB	*8)	60GB
MEMORY(Slot1)	512MB DDR333	256MB DDR333	256MB DDR333	512MB DDR333	512MB DDR333	256MB DDR333		256MB DDR333
MEMORY(Slot2)	512MB DDR333	256MB DDR333	256MB DDR333	-	=	-	*9)	256MB DDR333
QUANTITY[STANDARD/MAX]	1GBB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	256MB/2GB]	512MB/2GB
OPT-DRIVE	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	Combo	Combo	*10)	DVD+/-RW DL
AC adaptor	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11
Battery	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA
Wireless LAN	0	0	0	0	0	0	*11)	0
W-Mouse	X	Х	Х	Х	Х	Х	Х	Х
Memory Card Adapter	X	Х	Х	Х	Х	Х	X	X
USB FLOPPY DISK DRIVE	Х	Х	Х	Х	Х	Х	Х	Х
os	XP Home	XP Home	XP Pro	XP Pro	XP Pro SMB	XP Pro SMB	XP Pro/XP Pro SMB /XP Home	XP Home

- The model that is accompanied by asterisk(*) is the CTO model.
- For the equipment configuration, refer to the CTO Information.
- The trademarks or registered trademarks of above, refer to page2.

^{*6)}Celeron-M 360,Pentium-M 730,Pentium-M 740,Pentium-M 750,Pentium-M 760,Pentium-M 770*7)NV44M,915GM *8)100GB,80GB,60GB,40GB,30GB


					EU				
	VGN-FS195XP	VGN-FS115Z	VGN-FS115S	VGN-FS115M	VGN-FS115E	VGN-FS195VP	VGN-FS115B	VGN-FS115ZR	VGN-FS115MR
CPU	Pentium-M 740(Do1.73)	Pentium-M 740(Do1.73)	Pentium-M 740(Do1.73)	Pentium-M 730(Do1.6)	Celeron-M 360(Do1.6)	Pentium-M 730(Do1.6)	Pentium-M 730(Do1.6)	Pentium-M 740(Do1.73)	Pentium-M 730(Do1.6)
Graphic	NV44M	NV44M	NV44M	NV44M	915GN	NV44M	915GM	NV44M	NV44M
	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA	15.4"WXGA
LCD	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)	(Clear Black)
HDD	100GB	100GB	80GB	80GB	60GB	80GB	60GB	100GB	80GB
MEMORY(Slot1)	512MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	512MB DDR333	256MB DDR333	256MB DDR333	512MB DDR333
MEMORY(Slot2)	-	256MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	-	256MB DDR333	256MB DDR333	-
QUANTITY[STANDARD/MAX]	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB
OPT-DRIVE	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL	DVD+/-RW DL
AC adaptor	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11	AC19V11
Battery	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	BP2SA	0	0	BP2SA
Wireless LAN	0	0	0	0	0	0	Х	Х	0
W-Mouse	Х	Х	Х	Х	Х	Х	Х	Х	X
Memory Card Adapter	Х	X	Х	Х	Х	Х	Х	X	Х
USB FLOPPY DISK DRIVE	Х	Х	Х	Х	Х	Х	Х	Х	Х
os	XP Pro	XP Home	XP Home	XP Home	XP Home	XP Pro	XP Home	XP Home	XP Home

		AO												
	VGN-FS18CP	VGN-FS15C	VGN-FS18GP	VGN-FS18SP	VGN-FS18LP	VGN-FS18TP	VGN-FS15GP	VGN-FS15SP	VGN-FS15LP	VGN-FS15TP				
СРИ	Pentium-M 750(Do1.86)	Pentium-M 730(Do1.6)	Pentium-M 740(Do1.73)	<-	<-	<-	Pentium-M 730(Do1.6)	<-	<-	<-				
Graphic	NV44M	915GM	NV44M	<-	<-	<-	NV44M	<-	<-	<-				
	15.4"WXGA	15.4"WXGA	15.4"WXGA	<-	<-	<-	15.4"WXGA	<-	<-	<-				
LCD	(Clear Black)	(High Brightness)	(Clear Black)	ζ-	\ <u>`</u>	\	(High Brightness)	ζ-	`-	\ <u>`</u>				
HDD	60GB	40GB	80GB	<-	<-	<-	40GB	<-	<-	<-				
MEMORY(Slot1)	512MB DDR333	512MB DDR333	512MB DDR333	<-	<-	<-	512MB DDR333	<-	<-	<-				
MEMORY(Slot2)	-	-	-	<-	<-	<-	-	<-	<-	<-				
QUANTITY[STANDARD/MAX]	512MB/2GB	512MB/2GB	512MB/2GB	<-	<-	<-	512MB/2GB	<-	<-	<-				
OPT-DRIVE	Combo	Combo	DVD+/-RW DL	<-	<-	<-	Combo	<-	<-	<-				
AC adaptor	AC19V10	AC19V10	AC19V10	<-	<-	<-	AC19V10	<-	<-	<-				
Battery	BP2SA	BP2SA	BP2SA	<-	<-	<-	BP2SA	<-	<-	<-				
Wireless LAN	0	0	0	<-	<-	<-	0	<-	<-	<-				
W-Mouse	X	Х	Х	<-	<-	<-	Х	<-	<-	<-				
Memory Card Adapter	Х	х	Х	<-	<-	<-	Х	<-	<-	<-				
USB FLOPPY DISK DRIVE	Х	х	Х	<-	<-	<-	Х	<-	<-	<-				
os	XP Pro	XP Home	XP Pro	<-	<-	<-	XP Pro	<-	<-	<-				


The model that is accompanied by asterisk(*) is the CTO model. For the equipment configuration, refer to the CTO Information.

1-2. CTO Information


Model name:VGN-FS90PS Model number:PCG-791N OS:WinXP Pro




Model name:VGN-FS90S Model number:PCG-791N OS:WinXP Home



Confidential



Model name:VGN-FS500 Model number:PCG-792L OS:WinXP Home



Model name:VGN-FS500B Model number:PCG-792L OS:WinXP Pro

СРИ	Pemtium-M 770 A-1094-802-A CPU PM 2.13	Pemtium-M 760 A-1094-803-A CPU PM2.0	Pemtium-M 750 A-1094-804-A CPU PM 1.86	Pemtium-M 740 A-1094-805-A CPU PM 1.73	Pemtium-M 730 A-1094-806-A CPU PM 1.6	Celeron-M 360 A-1094-808-A CPU CEL-M 1.4
HDD	100GB A-1108-902-A ASSY HDD 100GB(TO)	80GB A-1108-903-A ASSY HDD 80GB(HI)	60GB A-1108-906-A ASSY HDD 60GB(HI)	40GB A-1108-910-A ASSY HDD 40GB(HI)	30GB A-1108-911-A ASSY HDD 30GB(HI)]
LCD	15.4/WXGA/ClearBlack A-1108-883-A ASSY LCD (HC-XGA-WLAN)(S)					
Graphics	NV44M	915GM				
Memory	256MB*1 6-707-029-01 IC HYS64D32020HDL-6-C	256MB*2 6-707-029-01*2 IC HYS64D32020HDL-6-C	512MB*1 6-705-096-01 IC HYS64D64020HBDL-6-C	512MB*2 6-705-096-01*2 IC HYS64D64020HBDL-6-C*2		
Opt.Drive	Combo A-1108-897-A ASSY ODD QSI(SBW 242C)	[COR] DVD+-RW A-1108-896-A ASSY ODD PANA(DVD+DL)	DVD-ROM A-1108-898-A ASSY ODD QSI(SDR-088)			
W-LAN	802.11b/g(Intel) 1-761-864-15 WIRELESS LAN CARD	802.11a/b/g 1-789-095-11 WIRELESS LAN CARD	None		1 4	

1-3. BTO Information

VGN-FS500 Series BTO Conpornent List Ver.1.0


NOTE: The parts marked " O " are commonly used in all models. For the component parts not shown here, please refer to the VGN-FS500* Service Manual.

		Produc	ct Code	28-3986-19	28-3986-20	28-3986-21	28-3986-22	28-3986-23	28-3986-24	28-3986-25	28-3986-26	28-3986-27	28-3986-28	28-3986-29
	Configuration Parts	Model Name												
		Part No.	Description	FS5001	FS500B01	FS500B02	FS500P01	FS500B03	FS500P02	FS500B04	FS500P03	FS500B05	FS500B06	FS500P04
	PM/Do/730/1.60GHz	A-1094-806-A	CPU PM1.60	0	0	0	0	-	-	-	-	-	-	-
	PM/Do/740/1.73GHz	A-1094-805-A	CPU PM1.73	-	ī	-	-	0	0	0	0	-	-	-
CPU	PM/Do/750/1.86GHz	A-1094-804-A	CPU PM1.86	-	ı	-	-	-	1	-	-	0	0	0
	PM/Do/760/2GHz	A-1094-803-A	CPU PM2.0	-	-	-	-	-	-	-	-	-	-	-
	PM/Do/770/2.13GHz	A-1094-802-A	CPU PM2.13	-	I	-	-	-	1	-	-	-	-	-
	40GB/2.5/4200	A-1108-910-A	ASSY HDD 40GB(HI)	0	0	-	-	-	-	_	-	_	_	_
HDD	60GB/2.5/4200	A-1108-906-A	ASSY HDD 60GB(HI)	-	ı	0	0	0	0	_	-	_	_	-
1100	80GB/2.5/4200	A-1108-903-A	ASSY HDD 80GB(HI)	-	ı	-	-	-	1	0	0	0	0	0
	100GB/2.5/4200	A-1108-902-A	ASSY HDD 100GB(TO)	-	Ī	-	-	-	ı	-	-	-	-	-
LCD	15.4/WXGA/HC	A-1108-883-A	ASSY LCD (HC-WXGA-WLAN)(S)	0	0	0	0	0	0	0	0	0	0	0
	256MB(256MB/DDR/333/SO-DIMMx1)	6-707-029-01	RAM Infineon 256MB	0	0	-	-	-	-	-	-	-	-	-
Memory	512MB(512MB/DDR/333/SO-DIMMx1)	6-705-096-01	RAM Infineon 512MB	-	Ī	0	0	0	0	0	0	0	0	0
	1024MB(512MB/DDR/333/SO-DIMMx2)	6-705-096-01	RAM Infineon 512MB	-	I	-	-	-	ı	_	-	_	-	-
ODD	Combo/12.7/x24	A-1108-897-A	MS01 ASSY ODD QSI(SBW 242C)	0	0	0	-	0	ı	0	-	0	0	-
CDD	DVD+-RW/12.7/x8/+DL	A-1108-896-A	MS01 ASSY PANA(DVD+DL)	-	ı	-	0	-	0	_	0	-	-	0
W-LAN	802.11b/g (Intel)	1-761-864-15	WIRELESS LAN CARD	0	0	0	0	0	0	-	-	0	-	0
VV-LAIN	802.11a/b/g (Intel)	1-789-095-11	WIRELESS LAN CARD	-	ı	-	-	-	1	0	0	-	0	-
Office	Bundle			-	I	-	_	-	Ī	-	ı	_	-	-
	WinXP HE			0	I	-	_	-	Ī	-	-	_	-	-
os	WinXP Pro			-	I	-	0	-	0	_	0	-	_	0
	WinXP Pro (SMB)			-	0	0	_	0	_	0	-	0	0	

			ct Code	28-3986-30	28-3986-31	28-3986-32	28-3986-33	28-3986-34	28-3986-35	28-3986-36	28-3986-37	28-3986-38	28-3986-40	28-3986-41
	Configuration Parts	Model Name												
		Part No.	Description	FS500P05	FS500B07	FS500P06	FS500P07	FS500P08	FS500B08	FS500P09	FS500P10	FS500P11	FS500BC	FS500PC
	PM/Do/730/1.60GHz	A-1094-806-A	CPU PM1.60	-	Ī	-	-	-	-	Ī	-	_	0	0
	PM/Do/740/1.73GHz	A-1094-805-A	CPU PM1.73	-	ı	-	-	-	ı	ı	-	-	-	-
CPU	PM/Do/750/1.86GHz	A-1094-804-A	CPU PM1.86	0	0	0	-	-	1	ı	-	-	-	-
	PM/Do/760/2GHz	A-1094-803-A	CPU PM2.0	-	ı	-	0	0	0	0	-	-	-	-
	PM/Do/770/2.13GHz	A-1094-802-A	CPU PM2.13	-	-	-	-	-	-	1	0	0	-	-
	40GB/2.5/4200	A-1108-910-A	ASSY HDD 40GB(HI)	-	-	-	-	-	-	-	-	-	-	-
HDD	60GB/2.5/4200	A-1108-906-A	ASSY HDD 60GB(HI)	-	-	-	-	-	-	-	-	-	0	0
HDD	80GB/2.5/4200	A-1108-903-A	ASSY HDD 80GB(HI)	0	-	-	-	-	0	0	-	-	-	-
	100GB/2.5/4200	A-1108-902-A	ASSY HDD 100GB(TO)	-	0	0	0	0	-	-	0	0	-	-
LCD	15.4/WXGA/HC	A-1108-883-A	ASSY LCD (HC-WXGA-WLAN)(S)	0	0	0	0	0	0	0	0	0	0	0
	256MB(256MB/DDR/333/SO-DIMMx1)	6-707-029-01	RAM Infineon 256MB	-	ı	-	-	-	ı	ı	-	-	-	-
Memory	512MB(512MB/DDR/333/SO-DIMMx1)	6-705-096-01	RAM Infineon 512MB	0	0	0	0	-	0	0	0	-	0	0
	1024MB(512MB/DDR/333/SO-DIMMx2)	6-705-096-01	RAM Infineon 512MB	-	ı	-	-	0	Ī	Ī	-	0	-	-
ODD	Combo/12.7/x24	A-1108-897-A	MS01 ASSY ODD QSI(SBW 242C)	-	0	-	-	-	0	ĺ	-	-	0	-
LODD	DVD+-RW/12.7/x8/+DL	A-1108-896-A	MS01 ASSY PANA(DVD+DL)	0	ı	0	0	0	ı	0	0	0	-	0
W-LAN	802.11b/g (Intel)	1-761-864-15	WIRELESS LAN CARD	-	0	0	-	-	0	0	-	-	0	0
W-LAIN	802.11a/b/g (Intel)	1-789-095-11	WIRELESS LAN CARD	0	ı	-	0	0	1	ı	0	0	-	-
Office	Bundle			-	ı	-	-	-	ı	ı	-	_	-	-
	WinXP HE			-	ı	-	-	-	İ	ı	-	-	-	-
os	WinXP Pro			0	ı	0	0	0	Ī	0	0	0	-	0
	WinXP Pro (SMB)			-	0	-	-	-	0	-	-	-	0	-


CHAPTER2. BLOCK DIAGRAM

2-1.VGN-FS series




CHAPTER3. FRAME HARNESS DIAGRAM

3-1 VGN-FS Series (TOP)



3-1 VGN-FS Series (BOTTOM)



3-2 Confidential

CHAPTER 4 EXPLODED VIEWS AND PARTS LIST


· The parts id compiled by blocks of a Palmrest and bottom etc. The sections of the parts list are different depending on the model. Please refer to list of contents shown in the below.

Section Page

Screws	
S-1.Screws	4-2
Palmerst	
P-1.Palmrest	4-3
Main Board	
M-1.Main Board	4-5
BOTTOM	
B-1.BOTTOM	4-7
CABINET KBCOVER	
C-1.CABINET KBCOVER	4-9
LCD	
L-1.LCD	4-10
ODD	
D-1.ODD	4-13
HDD	
H-1.HDD	4-14
ACCESSORIES	
A-1.ACCESSORIES	4-15
SUBSTITUTION PARTS LIST	
T-1.SUBSTITUTION PARTS LIST	4-18
DIP Switch	4-19
NOTE:	


- · The mechanical parts with no reference number in the exploded views are not supplied.
- · When two or more parts are shown, use the part described first as the main part.
- · The parts marked "%" are the "Customer Replacable Parts(CRP)" that can be replaced by Filed Customer Support. Especially the parts with the <&> mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replacable Parts(CRP), or the non-targetted parts by referring to the exploded view.

The components identified by mark /!\ or dotted line with mark / are critical for safely.



Screws are supplied with a whole set.


В0



Ref.No.	Part No		Description
В0	A-1091-349-A	&	SCREW ASSY
В1			SCREW M3 M3 6mm Black
B2			APPEARANCE SCREW M2 M2 1.6mm Black
В3			SCREW (M2), EXTERIOR VIEW M2 7mm Black
B4			GRIP, M2 M2 5mm Silver
В5			SCREW SPECIAL HEAD M3 3.5mm Silver
В6			SCREW (M2X4), SPECIAL HEAD M2 2mm Silver
В7			GRIP, M2 M2 3mm Black

Note: Screws are supplied with B0, a whole set.

P-1. Palmrest




P-1. Palmrest

P-1

Ref.No.	Part No.	<u>Description</u>
1	A-1108-885-A	MS01 ASSY CABINET PALMREST
2	1-963-519-11	MS01 CABLE DC IN
3	1-963-520-11	MS01 CABLE RJ COMBO
5	1-796-911-21	TOUCHPAD
6	1-830-442-11	MS01 TOUCHPAD FFC
7	X-2048-471-1	MS01 SUBASSY TOUCHPAD BRACKET
8	2-582-765-01	MS01 TOUCHPAD BUTTON
В7		GRIP, M2 M2 3mm Black

* :CTO Model

						J								ΑМ									EU									Α	0				
Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P	FORSOR	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZR	FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15LP	FS15TP
	1-479-153-11	KEYBOARD UNIT (JP)	•	•	Т	•	•					T														T		T	П		\Box	\Box		П		П	
	1-479-153-21	KEYBOARD UNIT (US)							•	•	•	•	.	•		•	•	•										•	•	•		コ		•		П	ヿ
	1-479-153-31	KEYBOARD UNIT (KR)											T													T			ヿ		T	•		П		•	コ
	1-479-153-41	KEYBOARD UNIT (TH)																								T			\Box		•	\exists		П	•	\Box	
	1-479-153-51	KEYBOARD UNIT (TW)										T														T			П			\exists	•	П		\Box	•
	1-479-153-61	KEYBOARD UNIT (RU)																								•	•		П			\Box		П		П	
	1-479-154-11	KEYBOARD UNIT (GB)																	•	•	•	•	•	•	•									П	П	П	
4	1-479-154-21	KEYBOARD UNIT (DE)																	•	•	•	•	•	•	•	T			П			\Box		П		П	
	1-479-154-31	KEYBOARD UNIT (CH)																	•	•		•		•	•							П		П		П	
	1-479-154-41	KEYBOARD UNIT (FR)																	•	•	•	•	•	•	•									П		П	
	1-479-154-51	KEYBOARD UNIT (IT)																	•	•	•	•		•	•	T					П	П		П	П	П	
	1-479-154-61	KEYBOARD UNIT (LA)													•					•		•												П		П	
	1-479-154-71	KEYBOARD UNIT (ES)																						•	•							П		П		П	
	1-479-154-81	KEYBOARD UNIT (SE)																		•		•												П		П	
	1-479-154-91	KEYBOARD UNIT (PT)																		•		•												П	П	П	
0	2-546-282-01	MS01 PALMREST LENS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
9	2-546-282-11	MS01 PALMREST LENS W/O PRINTING														•	•	•								寸	\Box	1	\neg		\Box	\neg		\sqcap	П	\Box	\neg
10	2-546-281-01	MS01 WLAN BUTTON	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
10	2-546-283-01	MS01 PRETENDED WLAN BUTTON														•	•	•				\Box				T	\Box	1	\Box	\Box	\Box	\neg		\sqcap	П	\Box	\neg



M-1. Main Board


M-1

	Ref.No.	Part No.	<u>Description</u>
	22	A-1093-218-A	MS01 ASSY THERMAL
	23	A-1093-219-A	MS01 ASSY THERMAL VGA
	27	A-1095-424-A	MS01 PWA ANTENNA
	28	2-546-280-01	MS01 DC IN BRACKET
	29	2-592-555-01	THERMAL SHEET VGA
	30	2-592-554-01	THERMAL SHEET
A [ADD]	31	1-819-779-11	PCMCIA SOCKET
A [ADD]	32	1-417-539-12	MDC MODULE
	B4		GRIP, M2 M2 5mm Silver
4 [ADD]	В7		GRIP, M2 M2 3mm Black

* : CTO Model

														ΑM									EU_								ΑC)			
	Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	F5550	FSSSOP	FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B FC1157P	FC115MD	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15LP FS15TP
	21	A-1108-887-A	MS01 PWA ALL (FOR HIGH)(NV44M)	•				•	•							•	•	•	•	•	•	•		•	•	•	•	•	•	•	•				• •
	21	A-1108-888-A	MS01 PWA ALL (FOR LOW)(915GM)		•	•	•	•	•	• •	•	• •	• •	•	•	•	•	•					•		•										
		A-1094-802-A	CPU PM2.13					•	•	\perp						•	•	•															\perp		
(ADD)		6-707-261-01	CPU PM2.13					•	•							•	•	•																	
		A-1094-803-A	CPU PM2.0													•	•	•															\perp		
(ADD)		6-707-260-01	CPU PM2.0						\perp	\perp						•	•	•															\perp		
		A-1094-804-A	CPU PM1.86													•	•	•									•						\perp		
(ADD)	24	6-707-259-01	CPU PM1.86													•	•	•									•								
		A-1094-805-A	CPU PM 1.73	•				•	•	•						•	•	•	•	•	•				•				•	•	•	•			
(ADD)		6-707-258-01	CPU PM 1.73	•				•	•	•						•	•	•	•	•	•				•				•	•	•	•			
		A-1094-806-A	CPU PM1.6		•			•	•	'	•	• •	• •	•	•	•	•	•				•		•	•	<u></u>		•					• •	•	• •
A [ADD]		6-707-252-01	CPU PM1.6		•			•	•	•	•	• •	•	•	•	•	•	•				•		•	•	•		•					•	•	• •
		A-1094-808-A	CPU CEL-M1.4			•	•	•	•							•	•	•					•												
A [ADD]		6-707-263-01	CPU CEL-M1.4			•	•	•	•							•	•	•					•												
	25	6-705-096-01	RAM Infineon 512 MB					•	•	•		•	• •			•	•	•	•					•			•		•	•	•	•			
		6-707-029-01	RAM Infineon 256 MB	•	•	•	•	•	•	•	•	•		•	•	•	•	•		•	•	•	•		• •	<u></u>		•					• •	•	• •
(DEL)		1-761-864-15	WIRELESS LAN CARD (B/G)							• •	•	• •	• •	•	•	•	•	•									-	-							
	26	1-761-864-25	WIRELESS LAN CARD (B/G)	•	•	•	•	•	•																										
A [ADD]		1-761-864-34	WIRELESS LAN CARD (B/G)																•	•	•	•	•	•	• •	<u> </u>	•	•	•	•	•	•	• •	•	• •
		1-789-095-11	WIRELESS LAN CARD (A/B/G)													•	•	•																	


B-1.Bottom



B-1. Bottom B-1


	Ref.No.	Part No.		Description	
	41	X-2050-581-1		MS01 ASSY CABINET BOTTOM	
	42	X-2050-587-1	&	MS01 ASSY HDD DOOR	
	43	X-2050-582-1	&	MS01 ASSY RAM DOOR	
	44	2-546-276-01		MS01 COVER THERMAL OUTLET	
<u>4</u> [CHG]	45	2-546-274-02	&	MS01 RUBBER FOOT	
	В1			SCREW M3 M3 6mm Black	
	В3			SCREW (M2), EXTERIOR VIEW M2 7mm Black	

: CTO Model AM EU FS195XP FS520B FS115E FS115MR FS530B FS195VP FS115ZR FS550P FS540P FS550F FS115Z FS115S FS115M FS115B FS18CP FS18SP FS18LP FS18TP FS15GP FS15SP FS15LP FS15TP FS50B FS90PS FS500P* FS18GP FS70B FS30B FS570 FS550 FS500B* FS15C FS500* FS20 FS90* Ref.No. Part No. Description 1 [DEL] • -• 2-587-200-01 LABEL, MODEL NUMBER(J) /\ [ADD] 2-587-204-01 LABEL, MODEL NUMBER (JCTO) • • • • • • 2-587-201-01 LABEL, MODEL NUMBER(U) 2-586-102-01 LABEL, MODEL NUMBER (UCTO) 2-586-102-11 LABEL, MODEL NUMBER (UCTO) 2-590-071-01 LABEL, MODEL NUMBER (UCTO) 2-587-203-01 LABEL, MODEL NUMBER(LA) 2-587-202-01 LABEL, MODEL NUMBER(E) 2-587-205-01 LABEL, MODEL NUMBER(C)(CAW) 2-587-205-11 LABEL, MODEL NUMBER(C)(CBX) 2-587-206-01 LABEL, MODEL NUMBER (IAWEHK) 2-587-206-11 LABEL, MODEL NUMBER (IBWEHK) 2-587-207-01 LABEL, MODEL NUMBER (IAWETH) 2-587-207-11 LABEL, MODEL NUMBER (IBWETH) 2-587-208-01 LABEL, MODEL NUMBER (IAWW) 2-587-208-11 LABEL, MODEL NUMBER (IBWW) 2-587-209-01 LABEL, MODEL NUMBER (IAWK) 2-587-209-11 LABEL, MODEL NUMBER (IBWK) 4-681-432-01 • • SPECIAL SCREW (M2)(SPIN)



	Ref.No.	Part No.	<u>Description</u>
٨	51	X-2048-486-1	MS01 CABINET KBCOVER
<u>√</u> 4\ [ADD]	B2		APPEARANCE SCREW M2 M2 1.6mm Black

L-1. LCD



L-1.LCD

L-1

	Ref.No.	Part No.		<u>Description</u>
	62	X-2048-459-1		MS01 SUBASSY LCD HOUSING
	63	2-546-200-01		MS01 LCD HOOK
	65	X-2050-578-1		MS01 SUBASSY LCD BEZEL
	67	2-546-209-01	&	MS01 LCD RUBBER ROUND
	68	2-587-393-01	&	MS01 LCD RUBBER ROUND DOWN
<u>4</u> [ADD]	70	2-546-203-01		MS01 HINGE LEFT
<u>4</u> [ADD]	71	2-546-204-01		MS01 HINGE RIGHT
<u>4</u> [ADD]	B1			SCREW M3 M3 6mm Black
	B4			GRIP, M2 M2 5mm Silver

* : CTO Model

						l .							Α	M									EU									Α	0				
Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P	FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZR	FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15LP	FS15TP
	A-1108-881-A	ASSY LCD (HC-SXGA+-WLAN)(S)	•				•	•																					\Box								
61	A-1108-883-A	ASSY LCD (HC-WXGA-WLAN)(S)		•	•	•	•	•	•	•	•					•	•	•	•	•	•	•	•	•	•	•	•	•	\Box								
	A-1108-878-A	ASSY LCD (BR-WLAN)(S)										•	•	•	•														•	•	•	•	•	•	•	•	•
64	1-963-756-11	MS01 LCD CABLE	•	•	•	•	•	•	•	•	•					•	•	•	•	•	•	•	•	•	•	•	•	•									
64	1-963-755-11	MS01 LCD CABLE										•	•	•	•														•	•	•	•	•	•	•	•	•
66	1-479-137-12	NEC-TOKIN LCD INVERTER (dual)	•	•	•	•	•	•	•	•	•					•	•	•	•	•	•	•	•	•	•	•	•	•									
66	1-478-805-12	NEC-TOKIN LCD INVERTER (single)										•	•	•	•														•	•	•	•	•	•	•	•	•
	2-587-211-01	ID LABEL3060 (CDS)(JAX)	•																										\Box			\Box					
	2-587-211-11	ID LABEL3060 (CDS)(JBX)		•																																	
	2-587-211-21	ID LABEL3060 (CDS)(JCX)			•																								\Box								
	2-587-211-31	ID LABEL3060 (CDS)(JDX)				•																															
	2-588-021-01	ID LABEL3060 (JCTO)					•																														
	2-588-021-11	ID LABEL3060 (JCTO)						•																					\Box								
69	2-589-160-11	ID LABEL3060 (CDS)(UBXE)							•																												
	2-589-160-21	ID LABEL3060 (CDS)(UCXE)								•																											
	2-589-160-31	ID LABEL3060 (CDS)(UCWE)									•																										
	2-589-160-41	ID LABEL3060 (CDS)(UDWE)										•																									
	2-589-160-51	ID LABEL3060 (CDS)(UEWE)											•																								
	2-589-160-61	ID LABEL3060 (CDS)(UFWE)												•																							
	2-589-160-81	ID LABEL3060 (CDS)(UHXS)													•																						

* : CTO Model

				<u> </u>			. 	· · ·																				—								\neg
	1		_]							Α	М						-	- 1	- 1	EU			_	\perp	_				AO	—			
Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P	FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FSI ISZK	FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP FS15GP	FS15SP	FS15LP	FS15TP
	2-586-104-01	ID LABEL3060 (UCTO)															•																			
	2-586-104-11	ID LABEL3060 (UCTO)																•								Ì					T	\Box			1	
	2-586-104-21	ID LABEL3060 (UCTO)														•														\top	\top					
	2-589-161-01	ID LABEL3060 (CDS)(EAW)																	•																	
	2-589-161-11	ID LABEL3060 (CDS)(EBX)																		•																
	2-589-161-21	ID LABEL3060 (CDS)(ECX)																			•													I	T	
	2-589-161-31	ID LABEL3060 (CDS)(EDX)																				•									\Box				I	
	2-589-161-41	ID LABEL3060 (CDS)(EEX)																					•													
	2-589-161-51	ID LABEL3060 (CDS)(EFW)																						•												
	2-589-161-61	ID LABEL3060 (CDS)(EGX)																							•											
69	2-589-161-71	ID LABEL3060 (CDS)(EHXRRU)																							•	•										
69	2-589-161-81	ID LABEL3060 (CDS)(EJXRRU)																									•									
	2-588-196-01	ID LABEL3060 (CDS)(CAW)																										•								
	2-588-196-11	ID LABEL3060 (CDS)(CBX)																											•							
	2-588-197-01	ID LABEL3060 (CDS)(IAWEHK)																												•						
	2-588-197-11	ID LABEL3060 (CDS)(IAWETH)																										\perp			•			\perp	\perp	
	2-588-197-21	ID LABEL3060 (CDS)(IAWK)																														•				
	2-588-197-31	ID LABEL3060 (CDS)(IAWW)																															•			
	2-588-197-41	ID LABEL3060 (CDS)(IBWEHK)																															•	,		
	2-588-197-51	ID LABEL3060 (CDS)(IBWETH)																																•		
	2-588-197-61	ID LABEL3060 (CDS)(IBWK)																																\perp	•	
	2-588-197-71	ID LABEL3060 (CDS)(IBWW)																																		•

	Ref.No.	Part No.	Description
4 [ADD]	83	2-546-291-01	MS01 ODD BRACKET BACK
4 [ADD]	84	2-546-292-01	MS01 ODD BRACKET FRONT
	B4		GRIP, M2 M2 5mm Silver
	В6		SCREW (M2X4), SPECIAL HEAD M2 2mm Silver
		2	A [ADD] B6 B6 B6 B6 B6 B1 B4 [ADD] *: CTO Model

				L		J	l							Α	M									EU								- /	٩O				
	Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P	FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZR	FS115MR	FS18CP	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15LP	FS15TP
		A-1108-893-A	MS01 ASSY ODD PANA(SM+DL)	•	•	•		•	•																												
⚠ [ADD]		A-1108-895-A	MS01 ASSY ODD PANA(SM+SL)	П			•	•	•																												
	81	A-1108-896-A	MS01 ASSY ODD PANA(DVD+DL)	\sqcap						•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•				
		A-1108-897-A	MS01 ASSY ODD QSI (SBW 242C)	\Box				•	•					•	•		•	•	•										•	,				•	•	•	•
		A-1108-898-A	MS01 ASSY ODD QSI (SDR-088)	\sqcap													•	•	•											\top							
		X-2048-479-1	SUBASSY ODD BEZEL PANA	•	•	•		•	•																												
		X-2048-480-1	SUBASSY MULTI BEZEL(HI)	•	•	•		•	•																					1							
		X-2050-540-1	SUBASSY ODD BEZEL PANA	\Box			•	•	•																												
4 [ADD]	82	X-2048-481-1	SUBASSY ODD BEZEL PANA	П						•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•				
		X-2048-482-1	SUBASSY ODD BEZEL SONY	П						•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	T					
		X-2048-577-1	SUBASSY ODD BEZEL QSI	П				•	•					•	•		•	•	•										• (,				•	•	•	•
		X-2050-541-1	SUBASSY ODD BEZEL QSI	П			İ										•	•	•				T		1												

H-1.HDD

B5

(ADD)


H-1

Ref.No. Part No. Description

4 [ADD] A-1092-487-A MS01 SUBASSY HDD BRACKET

4 [ADD] SCREW (M2), EXTERIOR VIEW M2 7mm Black

SCREW SPECIAL HEAD M3 3.5mm Silver




*: CTO Model

					J]							ΑI	М									EU									Α	0				
Ref.No.	Part No.	Description	FS70B	FS50B	FS30B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P	FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZR	FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15LP	FS15TP
	A-1108-901-A	MS01 ASSY HDD 100GB(FJ)							•										•	•						•											
	A-1108-902-A	MS01 ASSY HDD 100GB(TO)					•	•																													
	A-1108-903-A	MS01 ASSY HDD 80GB(HI)	•				•	•		•	•	•									•	•					•			•	•	•	•				
	A-1108-904-A	MS01 ASSY HDD 80G(FJ)		•																																	
91	A-1108-905-A	MS01 ASSY HDD 80G(TO)			•	•																		•													
	A-1108-906-A	MS01 ASSY HDD 60GB(HI)					•	•					•		•	•	•	•					•		•			•									
	A-1108-909-A	MS01 ASSY HDD 40G(TO)					•	•																										•	•	•	•
	A-1108-910-A	MS01 ASSY HDD 40GB(HI)												•		•	•	•											•								
	A-1108-911-A	MS01 ASSY HDD 30GB(HI)														•	•	•												\Box					\Box		

A-1. ACCESSORIES

















The components identified by mark \triangle or dotted line with mark \triangle are critical for safely. Replace only with part number specified.

					*	: C	TO	Mo	de																									
							J			<u> </u>			/	М								EU_				Щ,				AO)			
	Ref No	Part No.		Description	FS70B	FS50B	FS30B	FS90PS*	FS90S*	FS570	FS550	FS550P	FS530B	FS520B	FS550F	FS500 *	FS500B*	FS195XP	FS115Z	FS115S	FS115M	FS115E FS195VP	FS115B	FS115ZR	FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15SP	-S15LP	FS15TP
<u>∕3</u> [CHG]	2001	1-478-615-11	&	MEMORY CARD ADAPTER	•	•	• •							 -	_	- 		╁═		_	_	_	 -	╁═	1=	Ħ		十	7	=+	=+=	╁	十	Ħ
3 [CHG]	2002	1-828-502-41	<u> </u>	CORD, CONNECTION(USB 5P)				•	•												Ť					П		十	\top	\top	1		\dagger	П
<u>∕3</u> [CHG]	2003	1-417-440-11	&	WIRELESS RECEIVER				•	•																	П		\exists		\top	\top		\top	П
[CHG]	2004	1-476-818-21	&	FDD VGP-UFD1		•	•																			\Box		寸	\exists	十	\top		T	П
		1-827-160-21	&	POWER CORD FOR JP	•	•	•	•	•																	П		\exists		\top	\top		\top	П
		1-829-237-21	&	POWER CORD FOR US						•	•	• (•	•	•	•	• •									П	\top	十	\top	十	\top		T	П
		1-823-935-51	&	POWER CORD FOR E(GB)														•	•	•	•	• •	•			П		T						П
		1-827-481-21	&	POWER CORD FOR E(NON GB)				T										•	•	•	•	•	•			П		\top	T	\top	\top		\top	
<u>∕3</u> [CHG]	<u>^</u> 2005	1-830-375-11	&	POWER CORD FOR E(RU)																				•	•			\exists						
		1-823-947-32	&	POWER CORD FOR I(KOREA)																						П		T		•			•	
		1-829-237-21	&	POWER CORD FOR I(TAIWAN)																											•			•
		1-827-481-21	&	POWER CORD FOR I(THAILAND)																								•	•		1	•		
		1-782-476-22	&	POWER CORD FOR C																						•	•	\Box		\Box				
		1-479-116-11	&	ADAPTER AC19V11	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•											
	<u>^</u> 2006	1-479-114-11	&	ADAPTER AC19V10																						•	•	•	•	•	•	•	•	•
		1-479-231-11	&	ADAPTER AC19V12																				•	•									
		A-1114-325-A	&	BATTERY 9139 ASSY MAIN BP FOR JP	•	•	•	•	•																									Ш
<u>∕3</u> [CHG]	<u>^</u> 2007	A-1114-326-A	&	BATTERY 9139 ASSY MAIN BP FOR US						•	•	• •	•	•		•	• •																	Ш
		1-756-531-22	&	BATTERY PACK, LITHIUMION for EU/AP											•			<u> •</u>	•	•	•	• •	•	•	•	•	•	•	•	•	• •	• •	•	•
3 [CHG]	2008	1-796-824-41	&	MOUSE				•	•																			\perp	\perp	\perp	\perp	\perp	\perp	Ш
(CHG)	2009	1-770-019-51	&	ADAPTOR, CONVERSION PLUG				\perp																				•	ightharpoonup	\perp	<u></u> •	<u>, </u>	\perp	Ш
ADD]	-	2-585-822-01	&	MANUAL, INSTRUCTION	•	•	• •	<u> </u>	•																		\perp	ightharpoonup	\perp	\perp	\bot	\perp	\perp	Ш
	-	2-586-755-01		WELCOME MAT 3060 (EN/SP) (CDS)				_		•	•	• •	•	•	•	•	• •									Ш	\dashv	\dashv	\dashv	\bot	\bot	\bot	\perp	Ш
		2-584-781-11		HW SPECS, 3060 (E) A-1(GB)				\perp										<u> •</u>	•			•					\perp	ightharpoonup	\perp	\bot	\bot	\perp	\perp	Ш
		2-584-781-21		HW SPECS, 3060 (E) A-1(DE)			\perp	\perp	\perp	\sqcup		\perp		$oxed{oxed}$				<u> •</u>	•			<u> </u>			_	Ш	\perp	\perp	\perp	\perp	\perp	\perp	\perp	Ш
	-	2-584-781-31		HW SPECS, 3060 (E) A-1(FR)				\perp	\perp				\perp	$oxed{oxed}$			\perp	<u> •</u>	•			•	\downarrow		\perp	Щ	\perp	\perp	\perp	\perp	\perp	\perp	\perp	Щ
		2-584-781-41		HW SPECS, 3060 (E) A-1(IT)				\perp	\perp	\sqcup				$oxed{oxed}$				<u> •</u>	•			<u> •</u>			_	Ш	$\perp \downarrow$	\dashv	\perp	\perp	\perp	\perp	\perp	Ш
		2-584-781-61		HW SPECS, 3060 (E) A-1(NL)															•			•					Ш	\perp	\perp				\perp	

			*	: CT	0	Мо	<u>de</u> ļ																									
					J	_						ΔМ				_				EU				_		_	_	A	0			
Ref.No.	Part No.	Description	FS70B	FS50B	FS20	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS1157	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZR	FS115MR	FS18CP FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP FC151 P	FS15TP
	2-584-781-51	HW SPECS, 3060 (E) A-1(ES)															•				•											
	2-584-781-71	HW SPECS, 3060 (E) A-1(SE)																			•											
	2-584-781-81	HW SPECS, 3060 (E) A-1(SE)																			•											
	2-584-781-91	HW SPECS, 3060 (E) A-1(PT)															•															
	2-584-784-11	HW SPECS, 3060 (E) A-2(AGR)															•									\perp	L	<u> </u>				
	2-584-785-11	HW SPECS, 3060 (E) B(GB)																•	•	•		•										
_	2-584-785-21	HW SPECS, 3060 (E) B(DE)																•	•	•		•				\perp	L	<u> </u>				
	2-584-785-31	HW SPECS, 3060 (E) B(FR)																•	•	•		•					$oxed{oxed}$					
	2-584-785-41	HW SPECS, 3060 (E) B(IT)																•	•			•										
	2-584-785-51	HW SPECS, 3060 (E) B(ES)																	•			•					$oxed{oxed}$					
	2-584-785-61	HW SPECS, 3060 (E) B(NL)																	•			•								Ш		
	2-584-785-71	HW SPECS, 3060 (E) B(PT)																	•								$oldsymbol{ol}}}}}}}}}}}}}}}}}$			Ш	\perp	
	2-584-785-81	HW SPECS, 3060 (E) B(AGR)																	•												\perp	
	2-584-786-11	HW SPECS, 3060 (E) C																					•	•			$oldsymbol{ol}}}}}}}}}}}}}}}}}}$			Ш	\perp	
	2-585-320-31	TROUBLESHOOTING GUIDE ©																							• •	┸	╙	$oldsymbol{oldsymbol{oldsymbol{eta}}}$		Ш	\perp	
_	2-585-319-11	TROUBLESHOOTING GUIDE (D)																								•	•	$oxed{oxed}$		•	•	
	2-585-319-21	TROUBLESHOOTING GUIDE (D)																								┸	<u>↓</u>	•		Ш	•	,
	2-585-319-41	TROUBLESHOOTING GUIDE (D)																								\perp	\perp	$oldsymbol{ol}}}}}}}}}}}}}}}}}}$	•	Ш	\perp	•
	2-585-321-31	SPEC SHEET (3060G)																							• •	┸		$oldsymbol{oldsymbol{oldsymbol{eta}}}$		Ш	\perp	
	2-585-321-11	SPEC SHEET (3060G)														\perp										•	•			•	•	\perp
_	2-585-321-21	SPEC SHEET (3060G)																										•			•	
	2-585-321-41	SPEC SHEET (3060G)																											•			•
	2-586-077-11	SAFETY/REGULATIONS GUIDE 1																							• •					\Box		
	2-586-077-01	SAFETY/REGULATIONS GUIDE 1																								•	•	•	•	•	• •	•
-	2-318-620-02	CURTE VAIO	•	•	•	•	•																									

NOTE:

Please order below substitution parts if the parts with the same Ref. No. in page 4-2 to 4-17 are not available.

*		CTO	Ma	401
-1-	-	しれい	IVIO	aei

				ı		<u> </u>	-10		<u> </u>	÷																	$\overline{}$	—	—	—	-		—	—	
				1					_						١M								EU				+	_			A(<u>></u> _		—	
	Ref.No.	Part No.		Description	FS70B	FS50B	FS30B	F520	FS90PS*	FS90S*	FS570	FS550	FS550P	FS540P FS530B	FS520B	FS550F	FS500*	FS500P*	FS500B*	FS195XP FS115Z	FS115S	FS115M	FS115E	FS195VP	FS115B	FS115ZK FS115MR	FS18CP	FS15C	FS18GP	FS18SP	FS18LP	FS18TP	FS15GP	FS15SP	FS15TP
		6-707-508-01		RAM Micron 512 MB						•	•			• •			•	•		•				•					•	•	П			Т	
	25	6-707-611-01		RAM Hynix 256 MB	•	•	•	•	•	•		•	•		•	•	•	•	•	•	•	•	•		•	• •				П	П		•	•	
<u>∕2</u> [ADD]		6-707-648-01		RAM Hynix 512 MB					•	•				• •			•	•	•	•				•					•	•	П			Т	
1 [ADD]	66	1-478-805-31		NEC-TOKIN LCD INVERTER (single)										•	•	•												•	•	•	•	•	•	•	• •
		A-1108-894-A		MS01 ASSY ODD HITACHI DW	•	•	•		•	•																									
	81	A-1108-892-A		MS01 ASSY ODD SONY(DVD+DL)							•	•	•	•		•	•	•	•	• •	•	•	•	•	•	• •			•	•					
		A-1117-427-A		MS01 ASSY ODD SONY(DVD+DL)							•	•	•	•		•	•	•	•	• •	•	•	•	•	•	• •			•	•	Ш			\perp	
		A-1108-901-A		MS01 ASSY HDD 100GB(FJ)					•	•							•	•	•												Ш				\perp
		A-1108-902-A		MS01 ASSY HDD 100GB(TO)					\perp		•									• •						•					Ш			\perp	\perp
		A-1108-903-A		MS01 ASSY HDD 80GB(HI)		•	•	•																•							Ш				\perp
		A-1108-904-A		MS01 ASSY HDD 80G(FJ)	•		•	•	•	•		•	•	•			•	•	•		•	•		•		•		L	•	•	Ш	\Box		\perp	\perp
	91	A-1108-905-A		MS01 ASSY HDD 80G(TO)	•	•			•	•		•	•	•			•	•	•		•	•				•	<u> </u>		•	•	Ш	Ш		\perp	\perp
		A-1108-907-A		MS01 ASSY HDD 60G(FJ)				\perp	\rightarrow	•	_			•		•	•	•	•				•		•		$oldsymbol{\perp}$	$oxed{oxed}$			Ш	\Box	\bot	\perp	\bot
		A-1108-908-A		MS01 ASSY HDD 60G(TO)				1	•	•				•		•	•	•	•				•		•		$oldsymbol{\perp}$	L			Ш	\Box	\bot	4	
		A-1108-909-A		MS01 ASSY HDD 40G(TO)					\downarrow		_				•		•	•	•								$oldsymbol{\perp}$	$oxed{oxed}$			Ш	\Box	\bot	\perp	\bot
		A-1108-910-A		MS01 ASSY HDD 40GB(HI)					•	•																	<u> </u>			Ш	Ш	\Box	•	•	
2 [ADD]	I .	1-479-116-12	&	ADAPTER AC19V11	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	• •	•	•	•	•	•		$oldsymbol{\perp}$	$oxed{oxed}$			Ш	\Box	\bot	\perp	\bot
3 [CHG]	l	1-479-114-21	&	ADAPTER AC19V10	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	• •	•	•	•	•	•		\perp	ot	$\bigsqcup^{!}$		Ш	\Box	\perp	\perp	\bot
2 [ADD]		1-479-114-22	&	ADAPTER AC19V10	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	• •	•	·	•	•	•		•	•	•	•	•	•	•	• •	• •


DIP Switch

The DIP switch setting is following table.



The DIP switch setting is different depending the types of LCD. Set the DIP switch of CTO model in accordance with the [FOR CTO MODEL].








CHAPTER 5. OTHERS

5-1. Replacing the CPU


1. Removing the CPU

- 1. Insert a flat-blade screwdriver into the notch as shown illustration and rotate it so that the protrusion comes to the lock release position.
- 2. Pull the CPU gently upward to lift it out of the CPU socket



2. Installing the CPU

- 1. Align the triangle reference mark of the mark the CPU with that of the CPU socket and insert all the pins of the CPU to the corresponding holes of the CPU socket.
- 2. Insert the flat head (-) screwdriver into the specified position and rotate th screwdriver to the LOCK position.



Confidential

5-2. Wiring the W-LAN Cable* The MS01 PWA ANTENNA is installed also in the models without Wireless LAN. Refer to the instruction below to see how to wire the CABLE.



Using KAPTION TAPE to secure the Cable.



VGN-FS70B/FS50B/FS30B/FS20/FS90PS/FS90S (J)
VGN-FS570/FS550/FS550P/FS540P/FS530B/FS520B/FS500/FS500P/FS500B/FS550F (AM)
VGN-FS195XP/FS115Z/FS115S/FS115M/FS115E/FS195VP/FS115B/FS115ZR/ FS115MR (EU)
VGN-FS18CP/FS15C/FS18GP/FS18SP/FS18LP/FS18TP/ FS15GP/ FS15SP/ FS15LP/ FS15TP (AO)

List of VGN-F Series (As of June, 2005)

Service Manual			Model	Name					
Part No.	J			AM			EU		AO
	VGN-FS70B		VGN-FS570	VGN-FS520B		VGN-FS195XP	VGN-FS195VP	VGN-FS18CP	VGN-FS18TP
	VGN-FS50B		VGN-FS550	VGN-FS500	*	VGN-FS115Z	VGN-FS115B	VGN-FS15C	VGN-FS15GP
	VGN-FS30B		VGN-FS550P	VGN-FS500P	*	VGN-FS115S	VGN-FS115ZR	VGN-FS18GP	VGN-FS15SP
9-876-414-XX	VGN-FS20		VGN-FS540P	VGN-FS500B	*	VGN-FS115M	VGN-FS115MR	VGN-FS18SP	VGN-FS15LP
	VGN-FS90PS	*	VGN-FS530B	VGN-FS550F		VGN-FS115E		VGN-FS18LP	VGN-FS15TP
	VGN-FS90S	*							

*: CTO Model

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation

Revision History

Suffix	Ver.	Date	Contents	QM No.
-01	Ver.1	2005.02.17	First Edition	
-02	Ver. 2	2005.03.14	Page1-3,page1-4,Page 4-8,page4-13, Page 4-18	N2004_169CK
-03	Ver.3	2005.03.23	2 Page4-18	N2004_169CK
-04	Ver.4	2005.05.16	② Page4-7,Page4-8,Page4-15,Page4-16 Page4-18	N2005_010CK
-05	Ver.5	2005.09.28	4 Page4-5,Page4-6,Page4-8,Page4-9, Page4-10,Page4-11,Page4-13, Page4-14	N2005_028CK
<remarks></remarks>				

<Remarks>